

IN THE SPECIFICATION:

Please amend the following paragraphs:

[0023] FIG. 3 is a graph showing cyclic voltammograms of $K_3Fe(CN)_6$ recorded utilizing platinum wire and platinum coated carbon electrodes; and

[0024] FIG. 4 is a graph showing cyclic voltammograms of $K_3Fe(CN)_6$ recorded utilizing platinum coated electrode or pure platinum wire as a working electrode;

~~[0025] FIG. 5 is a graph exhibiting the reduction of oxygen in 1.0 M phosphoric acid solution using platinum coated carbon rods with five and ten cycle platinum loading; and~~

~~[0026] FIG. 6 is a graph showing the charge accumulation in 1.0 M sulfuric acid using platinum coated carbon rods with five and 10 cycle platinum loading using a hydrogen reference electrode.~~

[0044] FIG. 2 shows the cyclic voltammograms recorded by scanning the potential between 0 and -1.0 V for 20 cycles. Each complete cycle consists of a forward and a reverse scan. As can be seen from the diagram, there is a large change in current during the first four cycles. Subsequently, the changes in current from one cycle to the next decrease after several cycles, indicating the completion of electrode modification. In fact, very little change in current is seen after 10 cycles. Although the current did not change significantly after five cycles, platinum loading continues until it reaches saturation, which requires at least about 20 cycles. Amounts of platinum loaded on carbon surfaces, as determined by ion plasma coupled mass spectrometry (ICP-MS), are listed in Table 1. A uniform coating of the platinum on the carbon

surface was observed following the cyclic voltammetry experiments. However, the effective surface area as determined (data not shown) in ~~FIG. 6~~ is much larger than the geometric surface area of carbon articles. Accordingly, the actual platinum loading is lower than the values provided in Table 1 and in some instances the loading can be three times less for carbon articles. TABLE-US-00001

TABLE 1	Coated	Platinum	Contents	on	Carbon	Surfaces	Following	Cyclic	Voltammetry
	Platinum	Loading	mg/cm ^{sup.2}	Carbon	Rod/	Carbon	Paper/	Carbon	Rod/
	Carbon	Paper/	Carbon	Rod/	Carbon	Paper/	Carbon	Paper/	No. Of
	Pt-Blue	Pt-Blue	K.sub.2PtCl.sub.4	K.sub.2PtCl.sub.4	K.sub.2PtCl.sub.4	Cycles	(Stirring)	(Stirring)	(Without
	(Stirring)	(Stirring)	(Without	(Without	(Without	(Stirring)	(Stirring)	(Without	(Without
05	0.0448	0.0303	--	0.0401	0.1146	08	0.0889	--	--
10	0.1198	0.0761	--	0.0779	0.1838	15	0.1810	0.1176	0.0910
20	0.2158	0.1452	0.0980	0.1100	0.2058				

[0047] The efficacy of these platinum coated electrodes was demonstrated by their ability to reduce oxygen in phosphoric acid solution. In these series of experiments, platinum coated electrodes were used as working electrode and Ag/AgCl as the reference electrode for the reduction of oxygen by acquiring cyclic voltammograms of oxygen saturated phosphoric acid. ~~FIG. 5 shows tremendous~~ Tremendous enhancement of reduction current was found with ~~when~~ platinum coated carbon rods (~~chart b, c, d and e;~~ five, ten, twenty and twenty five cycles of coatings) compared to no reduction of oxygen with bare carbon rod (~~chart a~~ data not shown). Similar experiments in other conditions also demonstrate efficient reduction of oxygen.